




# COOKTOP PARTS

For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1  
(White on White) (Black) (Biscuit) (Stainless)

30" ELECTRIC CERAN  
FREESTANDING RANGE  
SELF CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
1	W10252706	Literature Instructions, Installation Template, Anti-Tip
	9757142	English/Spanish
	9757143	English/French
	W10200354	Owners Manual
	W10435364	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2	W10225448	Spring, Element
3	3196178	Screw
4		Cooktop
	W10162032	White
	W10162033	Black
	W10188932	Biscuit

Illus. No.	Part No.	DESCRIPTION
5		Element, Surface
	W10162040	3000/1900W – LF
	W10275048	3000/1400W – RF
	8273994	1200W – LR,RR
	9762851	Warm Zone, 120V
6	3195060	Hinge, Pin/Cooktop
7	3196169	Screw
8	W10170526	Pan, Radiant Elmt

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PANEL PARTS

For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1  
(White on White) (Black) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	W10184433	Endcap White LH
	W10184434	White RH
	W10184437	Black LH
	W10184438	Black RH
	W10184435	Biscuit LH
	W10184436	Biscuit RH
2	W10182322	Bracket, Console
3		Panel, Backguard
	W10201507	White
	W10201509	Black
	W10201508	Biscuit
	W10201510	Stainless

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

4	W10434452	Switch, Infinite LF,RF (Dual)
5	W10295576	Switch, Infinite LR,RR (Single)
6		Active Overlay Assembly
	W10224757	White
	W10224758	Black
	W10224759	Biscuit
7		Knob, Infinite
	W10154955	White
	W10155337	Black
	W10155338	Biscuit


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

8	W10134247	Shield, Heat
9	8272473	Cover, Rear
10	W10157242	Control, Range
11	3196178	Screw
12	3400882	Screw
13		Screw
	3196166	White
	3196168	Black
14	3196200	Clip, Spring
15	8273564	Clip, Cover

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1**  
**(White on White) (Black) (Biscuit) (Stainless)**

**For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1**  
**(White on White) (Black) (Biscuit) (Stainless)**




**FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST**

**For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1**  
**(White on White) (Black) (Biscuit) (Stainless)**

**FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST**

# DRAWER AND RACK PARTS


For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1  
(White on White) (Black) (Biscuit) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	W10268578	Rack, Oven
2	W10296838	Drawer, Storage
3	W10174396	Bracket, Drawer
4		Rivet, Push
	3196814	White
	3196813	Black
5		Drawer Front
	8053339	White
	8053341	Black
	8272501	Biscuit
	W10282465	Stainless
6	8053334	Glide, Drawer
7	3196165	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

**For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1**  
**(White on White) (Black) (Biscuit) (Stainless)**



<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
10		Hinge, Door
	W10299227	Passive
	W10299224	Active
11		Glass, Outer Door
	W10118454	White
	W10118455	Black
	W10118456	Biscuit
12		Trim, Side
	8523172	White LH
	8523166	White RH
	8523171	Black LH
	8523165	Black RH
	8523173	Biscuit LH
	8523167	Biscuit RH
	W10113926	Stainless LH
	W10113925	Stainless RH

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
13	3196160	Screw
14		Trim, Lower
	8523175	White
	8523177	Black
	8523178	Biscuit
15	W10031790	Screw
16	W10137382	Bracket, Window
17	3196165	Screw
18	W1020060	Clip, Dr Mntg
19	W10031780	Screw
20	W10113759	Strap, Door

W10453606

# OPTIONAL PARTS

For Models: GFE461LVQ1, GFE461LVB1, GFE461LVT1, GFE461LVS1  
(White on White) (Black) (Biscuit) (Stainless)

Illus. No.	Part No.	DESCRIPTION
<b><u>REFINISHING MATERIAL</u></b>		
	242756	Touch-Up Self-Clean(1/2 Pt)
<b><u>INSULATION</u></b>		
	261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>		
	72017	White
	511873	White Porcelain (2 Oz.)

Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>		
	350930	White
	285006	Superior Black
	206922	Primer (White)
<b><u>PAINT, BULK (1 qt.)</u></b>		
	799344	White (Uncut)
<b><u>ACCESSORY PARTS</u></b>		
	241430	Foil, Aluminum Oven (18" x 25')
	3191048	Cleaner, Glass
<b><u>ANTI-TIP KIT</u></b>		
	W10017440	Anti-Tip Kit

Illus. No.	Part No.	DESCRIPTION
<b><u>WIRING HARNESS PARTS</u></b>		
	W10349661	Harness, Wire Cooktop Left
	W10349654	Harness, Wire Cooktop Right
	W10174460	Harness, Wire Cooktop
	W10157270	Harness, Wire Sensor/Dr Switch
	W10434318	Harness, Main
	9757339	Harness, Wire Bake, Hidden
	3196520	Clip, Wire
	3196173	Screw
	3196154	Screw, Ground

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST